

■TTL Settings Table

Camera Brand	Model	Sync System	Converter Ch	Camera Code
SONY	α 7IV	YS Converter S2	D3II	SONY-C
	α 7RIV	YS Converter S2	D3II	SONY-D
	α 7RV	YS Converter S2	D3II	SONY-D
	α 7SIII	YS Converter S2	D3II	SONY-C
	α 1	YS Converter S2	D3II	SONY-A
	α 9II	YS Converter S2	D3II	SONY-B
CANON	R3	UW Technics	Ch9	CANON-C
	R5	YS Converter CR	D1	CANON-E
	R5II	YS Converter CR	D1	CANON-E
		UW Technics	Ch9	CANON-C
	R7	UW Technics	Ch9	CANON-C
	5DMKIV	YS Converter C2	Verif.	Verif.
		UW Technics	Ch9	CANON-B
NIKON	90D	Built-in flash	N/A	CANON-A
	Z7II	YS Converter N1	D3II	NIKON-B
	Z6II	YS Converter N1	D3II	NIKON-B
	Z7	YS Converter N1	D3II	NIKON-B
		UW Technics	Ch2	NIKON-A
	Z6	YS Converter N1	D3II	NIKON-B
	Z5II	YS Converter N1	Verif.	Verif.
	D850	YS Converter N1	D3II	NIKON-C
		UW Technics	Ch2	NIKON-A
	Z8	UW Technics	Ch2	NIKON-B
	Z9	UW Technics	Ch2	NIKON-B
	D810	Built-in flash	N/A	NIKON-D
OM SYSTEM(OLYMPUS)	Z50II	Built-in flash	N/A	NIKON-E
	D750	Built-in flash	N/A	NIKON-D
	XZ-1	Built-in flash	N/A	OMSYSTEM-A
SEA&SEA	TG-6	Built-in flash	N/A	OMSYSTEM-A
	OM-1	LM3	N/A	OMSYSTEM-B
	DX-6G	Built-in flash	N/A	SEA&SEA-A
PANASONIC	DX-1G/2G	Built-in flash	N/A	SEA&SEA-B
	GH4/GH5	Built-in flash	N/A	OTHERS> PANASONIC-A
RICOH	GR DIGITAL IV	Built-in flash	N/A	OTHERS> DEFAULT CAM
Fujifilm	X10/X20/XQ1/XQ2	Built-in flash	N/A	OTHERS> DEFAULT CAM

※When using the UWT HSS TTL Converter, set the channel to Ch.9 for TTL and Ch.7 for HSS.

※If your camera model is not listed, please contact SEA&SEA for further information.

※Compatibility with Nauticam HSS TTL Converter for Nikon(NA-Z8/Z9/Z6III)(26601) is currently under evaluation.

※Compatibility with TTL Flash Trigger for Canon(26321) is under evaluation.